



Rocbolt® C22 Slim Keyed Lock for Laptops & Devices
Compatible with All Kensington® 3 to 7mm Keying Systems
Cleat™ Lock Slot System - 6' Carbon Steel Cable -
Includes 2 Keys

Congratulations!

On your new Rocbolt® Premium R22 Slim Combination Lock for Laptops & Devices. Rocbolt® locks are the easiest and most reliable way to secure your notebook computer and other devices with this lock option. The Rocbolt R22 Slim Keyed Lock protection is Compatible with Kensington® Keying Systems. with 6' Carbon Steel Cable.

Registering Your Rocstor Product

To help remember your personalized combination code please register your Lock and code online at www.rocstor.com/locks

Technical Support

Technical support is available to all registered users of Rocstor products. Technical Support contact information can be found on www.rocstor.com

Telephone Support

There is no charge for technical support except long-distance charges where applicable. Please visit www.rocstor.com Monday to Friday 9:00 am to 6:00 pm Pacific Standard Time.

Technical Support

United States: +1 818 727 7000

Canada: +1 877 855 1126

Please note the following when calling support:

Be prepared to provide the following information:
- Name, address, and telephone number
- The name of the Rocstor Rocbolt product
- Symptoms of the problem and how it led to this issue

Limited Two Year Warranty

Rocstor warrants this product against defects in material and workmanship for two years. Rocstor will supply, at its option, comparable new and rebuilt replacements for defective parts and will pay the labor charges to repair the product found to be defective. The dated bill of sale as evidence of the original purchase price along with the defective product is required.

Kensington Cleat is trademark of ACCO Brands. All other registered and unregistered trademarks are the property of their respective owners.




© 2018 Rocstor. Rocstor & Rocbolt is registered trade mark of Rocstorage, Inc. Any unauthorized copying, duplicating, or other reproduction of the contents hereof is prohibited without written consent from Rocstor. All rights reserved.

Instruction Guide


Y1RB002-B1

Manual de usuario
Manuel utilisateur
Manuale utente
Benutzerhandbuch
Handleiding
Manual do usuário


LOCK



UNLOCK



RESET COMBINATION



The preset combination is 0-0-0-0.

In order to set your own combination, use a flat screwdriver to press the reset button and clockwise rotate 90°. Turn the digil wheel to set your combination. Then twist the reset button back, and press button (A) to check and set the correct combination. Your combination is now set.

